

## Technical Data Sheet

Article-No.: **09995-L**  
 Brand:  
 Description: **dispenser bucket for nonwoven rolls without lid**



DIMENSIONS		
height	Ø top	Ø bottom
211 mm	190 mm	210 mm

PRODUCT DESCRIPTION							
material	<input checked="" type="checkbox"/> Polypropylene (PP)	<input type="checkbox"/> Polyethylene (PE)	<input type="checkbox"/> Cup: Polypropylene (PP) Lid: PET				
colour	<input type="checkbox"/> anthracite [A]	<input type="checkbox"/> blue [B]	<input type="checkbox"/> cedro [C]	<input type="checkbox"/> ocean green [CO]	<input type="checkbox"/> green [GR]	<input type="checkbox"/> green opaque [GO]	<input type="checkbox"/> gray [GRAY]
	<input type="checkbox"/> purple [L]	<input type="checkbox"/> light blue [LB]	<input type="checkbox"/> lime [LIME]	<input type="checkbox"/> mixed [MIX]	<input type="checkbox"/> orange [O]	<input type="checkbox"/> pink [P]	<input type="checkbox"/> red [R]
	<input type="checkbox"/> rose [ROSE]	<input type="checkbox"/> black [SCH]	<input type="checkbox"/> transparent [ ]	<input type="checkbox"/> violett [V]	<input checked="" type="checkbox"/> white [W]	<input type="checkbox"/> winered [WR]	<input type="checkbox"/> yellow [Y]
capacity	<input type="checkbox"/> 30 ml	<input type="checkbox"/> 100 ml	<input type="checkbox"/> 150 ml	<input type="checkbox"/> 180 ml	<input type="checkbox"/> 200 ml	<input type="checkbox"/> 250 ml	<input checked="" type="checkbox"/> 6,2 l
characteristics	<input type="checkbox"/> graduation	<input checked="" type="checkbox"/> disinfect (at min. 65°C)	<input type="checkbox"/> Dishwasher-safe according to EN 12875-1 + 12875-2		<input type="checkbox"/> opening 4 x 4 mm	<input type="checkbox"/> sterile	
suitable for article	<input checked="" type="checkbox"/> 09995-L-Lid	<input checked="" type="checkbox"/> 742025	<input checked="" type="checkbox"/> 742022	<input type="checkbox"/> L-09194	<input type="checkbox"/> L-09192		

REGULATORY AFFAIRS						
MD-Regulation (EU) 2017/745	<input type="checkbox"/> Class I	<input type="checkbox"/> Class II	<input type="checkbox"/> Class III	<input type="checkbox"/> sterile	<input type="checkbox"/> measuring function	<input checked="" type="checkbox"/> no medical device
in-vitro diagnostic-Regulation (EU) 2017/746	<input type="checkbox"/> Class A	<input type="checkbox"/> Class A sterile	<input type="checkbox"/> Class B	<input type="checkbox"/> Class C	<input type="checkbox"/> Class D	<input checked="" type="checkbox"/> no IVD
Food Contact (EG) 1935/2004	<input type="checkbox"/> acid foods	<input type="checkbox"/> aqueous foods	<input type="checkbox"/> fatty foods	<input type="checkbox"/> alcoholic foods	<input type="checkbox"/> dry foods	<input checked="" type="checkbox"/> not approved for food contact

## Technical Data Sheet

Article-No.: **09995-L**  
 Brand:  
 Description: **dispenser bucket for nonwoven rolls without lid**



LOGISTIC DATA SUBPACKING		
<b>general information</b>		
material	-	
pieces per subpacking	-	
GTIN subpacking anthracite [A]	-	
GTIN subpacking blue [B]	-	
GTIN subpacking cedro [C]	-	
GTIN subpacking ocean green [CO]	-	
GTIN subpacking green [GR]	-	
GTIN subpacking green opaque [GO]	-	
GTIN subpacking gray [GRAY]	-	
GTIN subpacking purple [L]	-	
GTIN subpacking light blue [LB]	-	
GTIN subpacking lime [LIME]	-	
GTIN subpacking mixed [MIX]	-	
GTIN subpacking orange [O]	-	
GTIN subpacking pink [P]	-	
GTIN subpacking red [R]	-	
GTIN subpacking rose [ROSE]	-	
GTIN subpacking black [SCH]	-	
GTIN subpacking transparent [ ]	-	
GTIN subpacking violett [V]	-	
GTIN subpacking white [W]	-	
GTIN subpacking wine red [WR]	-	
GTIN subpacking yellow [Y]	-	
<b>measures &amp; size</b>		
length	-	
width	-	
height	-	
<b>weights</b>		
size	net weight	brut weight
uni	-	-

LOGISTIC DATA PALETTE		
<b>general information</b>		
kind of palette	euro-palette	
<b>measures &amp; size</b>		
cartons per layer	-	
layer per palette	900	
height of the palette	200 cm	
<b>weights</b>		
size	net weight	brut weight
uni	144 kg	169 kg

LOGISTIC DATA OUTER PACKING		
<b>general information</b>		
material	bag	
subpackingen per outer packing	25	
GTIN outer packing anthracite [A]	-	
GTIN outer packing blue [B]	-	
GTIN outer packing cedro [C]	-	
GTIN outer packing ocean green [CO]	-	
GTIN outer packing green [GR]	-	
GTIN outer packing green opaque [GO]	-	
GTIN outer packing gray [GRAY]	-	
GTIN outer packing purple [L]	-	
GTIN outer packing light blue [LB]	-	
GTIN outer packing lime [LIME]	-	
GTIN outer packing mixed [MIX]	-	
GTIN outer packing orange [O]	-	
GTIN outer packing pink [P]	-	
GTIN outer packing red [R]	-	
GTIN outer packing rose [ROSE]	-	
GTIN outer packing black [SCH]	-	
GTIN outer packing transparent [ ]	-	
GTIN outer packing violett [V]	-	
GTIN outer packing white [W]	-	
GTIN outer packing wine red [WR]	-	
GTIN outer packing yellow [Y]	-	
<b>measures &amp; size</b>		
length	-	
width	212 mm	
height	213 mm	
<b>weights</b>		
size	net weight	brut weight
uni	4.000 g	4.005 g

## Technical Data Sheet

Article-No.: **09995-L**  
Brand:  
Description: **dispenser bucket for nonwoven rolls  
without lid**



### WARNINGS AND SAFETY INFORMATION

<b>storage / expiry date</b>	Store product in original packaging in a cool and dry place without additional weight, protect from direct sunlight. Do not store near ozone sources (laser printers, copiers). An individual risk assessment must be carried out in each case.
<b>use and control</b>	<p>Clean thoroughly before first use and after each use to maintain hygiene standards. Make sure that the product has no defects and is in good condition (no cracks, etc.).</p> <p>The following points must be observed when handling and reprocessing the dispenser systems in order to minimise the risk of contamination:</p> <p>Pushing back wipes that have already been removed or wringing out the disinfectant from the wipe over the bucket must be avoided.</p> <p>The dispenser system must be reprocessed when the wipes have been used up, but no later than after 28 days. Correct reprocessing of the dispenser systems is mandatory. The dispenser bucket should be thermally disinfected (at min. 65°C). Reprocessing is possible in a dishwasher or manually under the same hygienic conditions. If this is not possible, the inside and outside of the dispenser bucket must be wipe-disinfected with a fresh disinfectant wipe. Only when the dispenser bucket is completely dry can it be refilled with a roll of wipes and the disinfectant. The maximum service life of the dispenser system is 28 days. After this period, any remaining contents must be disposed of.</p>
<b>disposal</b>	The used product must be disposed of in accordance with the disposal regulations of the local waste disposal company.
<b>warnings</b>	Only ever use the product for its intended use. A check/risk assessment must be carried out to ensure that the product is suitable for the intended use.